



LEDLENSER HF6R


HF6R Core




HF6R Work




HF6R Signature




Magnetic Charge System




Battery Indicator




Transportation Lock




Low Battery Warning




Boost









Boost Overheat Warning




Lamp Head Rotation




Connecting System Adapter (HF6R Work/HF6R Signature)




Comfort Pad






Wall Holder (HF6R Work)



Digital Advanced Focus System



Helmet Adapter(HF6R Work)




Ledlenser GmbH & Co. KG
Kronenstrasse 5-7 • 42699 Solingen • Germany
Phone +49 212/5948-0 Fax +49 212/5948-200
info@ledlenser.com




HF6R_QUG_V0
2022.12.20
1J12A0503

LEDLENSER HF6R


HF6R Core/HF6R Work




Direct to Red Mode (HF6R Core/HF6R Work)



Direct to RGB Mode (HF6R Signature)



HF6R Signature



HF6R Core/HF6R Work

