


MODEL : 3AB/H-40



PARTS LIST (3AB/H-40)***WHEN ORDERING SPARE PARTS,PLEASE STATE ITEM No ,PART NO.AND DESCRIPTION.**

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
01	HS05080BW-35	HEX. SOC. HD. BOLT+SW	4	48	12504801	SET PLATE	1				
03	13900305	CAP	1	49A	12604901A	STAPLE GUIDE UNIT	1				
04	12100401	SEAL**	1	50	12605002	MAGAZINE	1				
05	12100501	SPRING**	1	51	12605101	PUSHER	1				
06	OR13824N	O RING**	1	52	12405202	SLIDE BLOCK	2				
07	11100702	GASKET**	1	53	11305301	SPRING**	2				
08A	13900801A	HEAD VALVE ASM.	1	54	11305401	ROD	2				
11	OR31824N	O RING**	1	55	11305502	SHAFT	1				
13	OR25735N	O RING**	1	56	11305601	SET BLOCK	2				
14A-1	16401401A	DRIVER ASSEMBLY**	1	58A	12505801A	END CORE ASM.	1				
14A-2	16401402A	DRIVER ASSEMBLY**	1	59	US05080B-10	UM. HD. BOLT	4				
17	13901903	COLLAR	1	63	HS04070B-10	HEX. SOC. HD. BOLT	2				
18	OR44431N	O RING**	1	64	HS05080B-16	HEX. SOC. HD. BOLT	1				
19	13301901	CYLINDER	1	65	LN0500N	LOCK NUT	1				
20	13902001	BUMPER**	1	66	11106601	COVER	1				
21	OR35020N	O RING**	1	67	12106401	AIR PLUG	1				
22	OR35735N	O RING**	1	68	OR40030N	O RING**	1				
23	13902301	BODY	1	69	12706901	BRACKET	1				
24	OR01919N	O RING**	2	70	13907001	COLLAR	1				
25	12602501	JOINT GUIDE	1	71	US05080B-06	UM. HD. BOLT	1				
26	11002601	SPRING	1	72	FW050120B-10	FLAT WASHER	1				
27	11002701	GUIDE SAFETY LEVER	1	73	12103301	SEAL	1				
29	LN0300N	LOCK NUT	1	74	13907403	EXHAUST COVER	1				
30	CH03050B-08	CAP. HD. SCREW	1								
31	12703101	SAFETY LEVER	1								
32	11103201	STEPPED PIN	2								
33	11006903A	TRIGGER VALVE ASSEMBLY^	1								
40A	15104501A	TRIGGER ASSEMBLY	1								
41	HS04070B-08	HEX. SOC. HD. BOLT	2								
42	14604201	NOSE COVER	1								
43	HS04070B-16	HEX. SOC. HD. BOLT	2								
44	HS05080BW-20	HEX. SOC. HD. BOLT+SW	2								
46	12604601	NOSE	1								
47	11304701	SET PLATE	1								