

## **UITSCHAKELING VAN DE ELEKTRONISCHE ANTI-SNIJBEVEILIGING**

**Bij het inschakelen van het gereedschap is de beveiligingsinrichting altijd ingeschakeld.**

**Om het apparaat uit te schakelen gaat u als volgt te werk:**

- 1) Schakel het product in**
  - 2) Activeer de messen**
  - 3) Houd de hendel voor het starten van het snijden ingedrukt totdat u het tweede geluid hoort.**
- totdat u het tweede geluid hoort. Het eerste geluid na ongeveer 2' geeft aan dat de messen in de gesloten; het tweede geluid terwijl u de hendel nog 2" ingedrukt houdt, geeft aan dat de uitschakeling van de beveiliging.**

## **VOLUNTARY DISENGAGEMENT OF THE ELECTRONIC ANTI-CUTTING DEVICE**

**When switching on the tool, the protective device protection device is always switched on.**

**To switch off the device, proceed as follows:**

- 1) Switch on the product**
  - 2) Activate the blades**
  - 3) Hold down the cutting start lever until you hear the second sound.**
- until the second sound is heard. The first sound after approx. 2' indicates that the blades are in the closed; the second sound while keeping lever pressed for a further 2" indicates that the disengagement of the safety device.**