



# Erersatzteile 9033-2



	HAZET No.	Bezeichnung	Name	Désignation	
101		Gehäuse	Housing	Boîtier	1
		Inhalt: 101	Contents: 101	Contenu: 101	
210		Federstift	Spring Pin	Goupille élastique	1
		Inhalt: 210	Contents: 210	Contenu: 210	
211		Auslösehebel	Trigger	Levier de déclenchement	1
		Inhalt: 211	Contents: 211	Contenu: 211	
301		Vorderer Ring	Front Ring	Anneaux avant	1
		Inhalt: 301	Contents: 301	Contenu: 301	
302		Lager-302	Bearing	Palier	1
		Inhalt: 302	Contents: 302	Contenu: 302	
303		Vordere Lagerscheibe	Front Bearing Plate	Rondelle roulement de roue avant	1
		Inhalt: 303	Contents: 303	Contenu: 303	
304		Rotor	Rotor	Rotor	1
		Inhalt: 304	Contents: 304	Contenu: 304	
305		Lamellen	Blades	Lamelles	5
		Inhalt: 305	Contents: 305	Contenu: 305	
306		Zylinder	Cylinder	Vérin	1
		Inhalt: 306	Contents: 306	Contenu: 306	
307		Einregelstift	Line-Up Pin		1
		Inhalt: 307	Contents: 307	Contenu: 307	

	<b>HAZET</b> No.	<b>Bezeichnung</b>	<b>Name</b>	<b>Désignation</b>	
308		Hintere Lagerscheibe	Rear Bearing Plate	Rondelle roulement de roue arrière	1
		Inhalt: 308	<i>Contents: 308</i>	<i>Contenu: 308</i>	
309		Lager	Bearing	Palier	1
		Inhalt: 309	<i>Contents: 309</i>	<i>Contenu: 309</i>	
310		Hintere Ring	Rear Ring	Anneaux arrière	1
		Inhalt: 310	<i>Contents: 310</i>	<i>Contenu: 310</i>	
311		Mittlerer Ring	Middle Ring	Anneaux midie	1
		Inhalt: 311	<i>Contents: 311</i>	<i>Contenu: 311</i>	
312		Wellenscheibe	Washer	Rondelle ondulée	1
		Inhalt: 312	<i>Contents: 312</i>	<i>Contenu: 312</i>	
313		Sicherungsdichtring	Lock Ring Seal	Joint d'étanchéité de sécurité	1
		Inhalt: 313	<i>Contents: 313</i>	<i>Contenu: 313</i>	
314		Motorachsen-Ausgleichswelle	Motor Shaft Balancer		1
		Inhalt: 314	<i>Contents: 314</i>	<i>Contenu: 314</i>	
315		Rotorschlüssel	Rotor Key		1
		Inhalt: 315	<i>Contents: 315</i>	<i>Contenu: 315</i>	
318		Seegering	Snap Ring	Circlip	1
		Inhalt: 318	<i>Contents: 318</i>	<i>Contenu: 318</i>	
319		Ausgleichswelle	Balancer Shaft		1
		Inhalt: 319	<i>Contents: 319</i>	<i>Contenu: 319</i>	
320		Vacuum-Schutzblech	Vacuum-Shroud	Tôle de protection vacuum	1
		Inhalt: 320	<i>Contents: 320</i>	<i>Contenu: 320</i>	
323		Anschlagpuffer	PAD		1
		Inhalt: 323	<i>Contents: 323</i>	<i>Contenu: 323</i>	
324		Kopfisolations-Wellenscheibe	Heat Isolation Washer	rondelle ondulée	1
		Inhalt: 324	<i>Contents: 324</i>	<i>Contenu: 324</i>	
401		Schalldämpfer Schraube	Muffler Screw		1
		Inhalt: 401	<i>Contents: 401</i>	<i>Contenu: 401</i>	
403		Vacuum-Adapter	Vacuum Adapter		1
		Inhalt: 403	<i>Contents: 403</i>	<i>Contenu: 403</i>	
404		Anschlussbuchse	Connector	Douille de raccordement	1
		Inhalt: 404	<i>Contents: 404</i>	<i>Contenu: 404</i>	
405		Zylinderstift	Dowel Pin	Goupille cylindrique	1
		Inhalt: 405	<i>Contents: 405</i>	<i>Contenu: 405</i>	
500	9033-02/7	Lager	Bearing	Palier	1
		Inhalt: 316, 317, 321, 322, 325, 326, 327	<i>Contents: 316, 317, 321, 322, 325, 326, 327</i>	<i>Contenu: 316, 317, 321, 322, 325, 326, 327</i>	
501	9033-02/6	Regler	<i>Regulator</i>	<i>Régulateur</i>	1
		Inhalt: 201, 202, 203, 204 (2X), 205	<i>Contents: 201, 202, 203, 204 (2x), 205</i>	<i>Contenu: 201, 202, 203, 204 (2x), 205</i>	
502	9033-02/4	Ventileinheit	<i>Valve Unit</i>	<i>Unité de soupape</i>	1
		Inhalt: 206, 207, 208, 209	<i>Contents: 206, 207, 208, 209</i>	<i>Contenu: 206, 207, 208, 209</i>	