



LEDLENSER HF4R


HF4R Core




HF4R Work




HF4R Signature




Magnetic Charge System




Battery Indicator




Low Battery Warning




Boost




Boost Overheat Warning




Transportation Lock





Lamp Head Rotation



Connecting System Adapter (HF4R Work/HF4R Signature)




Helmet Adapter (HF4R Work)




Ledlenser GmbH & Co. KG
 Kronenstrasse 5-7 • 42699 Solingen • Germany
 Phone +49 212/5948-0 Fax +49 212/5948-200
 info@ledlenser.com




HF4R Core/HF4R Work



Direct to Red Mode (HF4R Core/HF4R Work)



HF4R Signature



Direct to RGB Mode (HF4R Signature)

