



KL-0121-96 B / KL-0121-9600 B Clamping Pliers for Steering and Axle Boots



Product information

EN

 Read and understand before use!



www.gedore-automotive.com



GEDORE Automotive GmbH

Breslauer Straße 41
78166 - Donaueschingen
Postfach 1329
78154 Donaueschingen - GERMANY

+49 (0) 771 / 8 32 23-0
+49 (0) 771 / 8 32 23-90
info.gam@gedore.com
gedore-automotive.com

GEDORE TOOLS, INC.

Only for USA, Canada & Mexico / Sólo para EE.UU., Canadá y México
Seulement pour les USA, le Canada et le Mexique
7187 Bryhawke Circle, Suite 700
North Charleston, SC 29418, USA

+1-843 / 225 50 15
+1-843 / 225 50 20
info@gedoretools.com
gedore.com

Version 1 - 07/2021

0121-96B_EN210611.indd

Product description

KL-0121-96 B - Clamping pliers for steering and axle boots

Universal fit for VW-Audi , Seat, Skoda, BMW, Citroën, Mazda, Honda, Nissan, Ford, Opel and many more.

Alternative tools: VAG1682, VAG1682A, BMW 315200, Opel MKM-804

The clamping pliers permit proper compression of lug clamps as required by the tightening torque, as well as damage-free sealing of continuous anchor clamps. Required, for example, for axle boots, steering boots, coolant hoses, fuel lines, etc.

The design of the clamping pliers makes it easy to change the pliers jaws required for the respective application. Depending on the space available on the vehicle, these jaws can be mounted on the pliers either from the FRONT or from the SIDE.

Recommended accessories: 4549-05 - Torque spanner (10 ... 50Nm)

EN



Scope of delivery / Single part overview

Item	Part no.	Description	Qty.
A	KL-0121-9600 B	Hose clamp pliers	1
A1	KL-0121-9601 A	Pair of clamping pieces (pliers jaw)	1
-	KL-0121-9602 A	Bottom of the pliers	1
-	KL-0121-9603 A	Top of the pliers	1
-	KL-0121-9604 A	Connecting piece	1
-	KL-0121-9605 A	Spindle	1
-	KL-0121-9606 A	Bit insert 3/8"	1
-	KL-0121-9607 A	Left-hand thread nut	1
-	KL-0121-9608 A	Right-hand thread nut	1
-	KL-0121-9609 A	Bolt Ø10mm	1
-	KL-0121-9610 A	Handle	1
-	KL-0255-0024	Dowel pin Ø6 x 20mm	2
-	KL-0284-9007	Cheese-head screw M6 x 14mm	2
-	KL-0055-0011	Retaining ring Ø 8	1
B	KL-0121-9611-1	Hook (pliers jaw)	2

Specifications

Length: 260mm
 Weight: 490g
 Drive: 3/8"



📷1: Compressing lug clamps with pliers jaws [A1].





📷2: Locking anchor clamps with pliers jaws [B].




Pliers jaws front mounted.



Pliers jaws at side mounted.



📷3: Compressing lug clamps with tightening torque as specified by the manufacturer.



⚠️ Safety instructions and regulations

- ✔️ **Before using** the tool, read and understand all safety instructions and **follow** them for **safe use!**
- ✔️ Ensure that maintenance and repair work on motor vehicles is only carried out by trained specialists in specialist automotive workshops, taking into account occupational safety and accident prevention as well as the instructions of the vehicle manufacturer!
- ✔️ **Prior to each use**, check the tool **carefully** for damage, loose parts or unauthorised modifications. **Never** use it if you notice any such deficiencies!
- ✔️ Use the tool **as intended** and **always** observe the vehicle-specific application procedures in the vehicle manufacturer's repair manual!
- ✔️ **Always** wear your personal protective equipment (for example safety goggles, protective gloves, safety shoes) when working!

EN

Typical application

This application example describes the process of compressing lug clamps and continuous clamps.

- 1) First, select the pliers jaws appropriate for the type of clamp.
 - ✔️ For lug clamps, use pliers jaws [A1]. 📷1A
 - ✔️ For anchor clamps, use pliers jaws [B]. 📷1B
- 2) Mount the chosen pliers jaws, depending on the space conditions on the vehicle, either at the front 📷1B / 2B or at the sides 📷1C / 2C on the clamping pliers.
- 3) Apply the clamping pliers neatly and straight to the lug of the clamp or to the tensioning hooks of the anchor clamp.
 - ✔️ For lug clamps, use a torque spanner to turn the clamping pliers together to compress the lug clamp ear until the tightening torque required by the specifications of the manufacturer is reached. 📷3
 - ✔️ For anchor clamps, use a ratchet to turn the clamping pliers together until it locks into place in the detent step specified by the manufacturer. 📷2
- 4) Release and remove the clamping pliers and carry out the further work on the vehicle as specified by the manufacturer.

GEDORE-Werkzeugfabrik GmbH & Co. KG

Remscheider Straße 149
42899 - Remscheid
Postfach 120361
47873 Remscheid
GERMANY

Vertrieb DEUTSCHLAND

☎ +49 (0) 2191 / 596-0
☎ +49 (0) 2191 / 596-230
✉ info@gedore.com
🌐 www.gedore.com

Sales INTERNATIONAL

☎ +49 (0) 2191 / 596-910
☎ +49 (0) 2191 / 596-911
✉ info@gedore.com
🌐 www.gedore.com

GEDORE TOOLS, INC.

Only for USA, Canada & Mexico
Sólo para EE.UU., Canadá y México
Seulement pour les USA, le Canada et le Mexique
7187 Bryhawke Circle, Suite 700, North Charleston, SC 29418, USA

☎ +1-843 / 225 50 15
☎ +1-843 / 225 50 20
✉ info@gedoretools.com
🌐 www.gedoretools.com

Worldwide GEDORE service centers and offices are listed on the Internet at: www.gedore.com

GEDORE Automotive GmbH

Breslauer Straße 41
78166 - Donaueschingen
Postfach 1329
78154 Donaueschingen
GERMANY

Vertrieb DEUTSCHLAND

☎ +49 (0) 771 / 8 32 23-0
☎ +49 (0) 771 / 8 32 23-90
✉ info.gam@gedore.com
🌐 gedore-automotive.com



www.gedore-automotive.com